

1 1/4"hexagon screw	C. Marine and	installing bracket	
Bracket	E S	Installing shade(clutch side)	
Bracket	A COL	Installing shade(end plug side)	
2" flat head screw	81 TANKALAR	Installing safety device	
2 Manual roller shade with Fascia			
Hardware Picture Usage			
	Tieture	Ű	
1 1/2" hexagon screw	6 January	installing bracket	
Bracket	e Har	Installing shade(clutch side)	
Bracket		Installing shade(end plug side)	
Bracket end cap		Outside mount only	
2" flat head screw	O- TOTOTOTO	Installing safety device	
3、 Manual roller shade with Cassette (1) Small Cassette			
Hardware	Picture	Usage	
1 1/4" hexagon screw	Company.	installing mounting bracket	
1 1/4" L shape mounting bracket	200	mounting	
2" flat head screw	OF THEFT	Installing safety device	
(2) Large Cassette			
Hardware	Picture	Usage	
1 1/4" hexagon screw	C. Marine Marine	installing mounting bracket	
79x45mm mounting bracket		mounting shade	
2" flat head screw	A - THERE AND	Installing safety device	
Manual roller shade installation or removal			
Installation: The brackets for both ends of the shade should be on			



തി

Install shade to the brackets

Install shade (clutch side) to the clutch bracket, and then the end plug side to the "V" of end plug bracket, rotate the removable pin of the end plug bracket till the shade is firmly installed.



• Attach Fascia and end cap after shade is installed. (note: end cap is for outside mount only)

Hook the top lip of the Fascia to the top of bracket, swing the bottom of the Fascia towards the bracket and gently press at the bottom of the Fascia until the lip on the Fascia engages and snaps locked to the bracket.



After Fascia is installed, affix end caps to the brackets.



Removal:

1. Detach the bottom lip of the Fascia from the bracket, and then lift the Fascia upward slightly. The top lip of Fascia will be away from the bracket and the Fascia is removed.



2、 After Fascia is removed, rotate the removable pin on bracket, detach the shade (end plug side) from "V" of the bracket and remove the clutch side from the bracket.



Manual roller shade with Cassette

installation or removal

Brackets Installation

 Mount one bracket on each end of the shade. The distance from center of bracket to the end of the shade is 1 1/4". If more than 2 brackets are needed, the distance between each 2 brackets should be even.



For Inside Mount

•

The distance from front mounting hole of brackets to front edge of window frame should be more than 3/4". Ensure both of the brackets are at the same horizontal line. Each bracket needs two 1 1/4" hexagon screws for installing.



For Outside Mount

• The top of each bracket is parallel with the edge of window frame. The distance from mounting holes of brackets to front edge of window frame should be more than 3/4". Both of the brackets should be at the same horizontal line. Each bracket needs two 1 1/4" hexagon screws for installing.





1, Small Cassette installation or removal

Installation

Snap the flange on top of Cassette to the front mounting lip of the bracket, and then turn the Cassette upwards to make sure the flange on back of Cassette clasp to the lower mounting lip of the bracket. As shown below:



• Removal(the same for both inside & outside mount)

Push the Cassette horizontally backward, and then turn the Cassette downward to release the flange on top of the Cassette from the front mounting lip of the bracket. As shown below:



2, Large Cassette installation or removal Installation

Snap the flange on front of the Cassette to the front mounting lip of the bracket, and then turn the Cassette upwards to make sure the flange on back of Cassette and the flange of the end cap clasp to the lower mounting lip of the bracket. As shown below:



Note: when 3 mounting brackets are needed, it is suggested to install the shade to the middle bracket

firstly, and then both ends of shade to the remaining brackets.

• Removal(the same for both inside & outside mount)

Insert the end of a flat head screwdriver into the gap between top of Cassette and the bracket. Pry the screwdriver to release the Cassette from the bracket. As shown below:



Note: when there are 3 mounting brackets, it is suggested to remove both ends of the shade firstly, and then detach the shade from the middle bracket.

Safety device installation manual

• The chain cord should be fully extended when fixing the safety device





Shade is heavy. Be careful during installation.

N300449